


# ProPower™ CE RMD Series

Rack Mount Distribution

Rack mounted power distribution with optional dimming and data distribution. Custom-configured in ATA flight cases to your specifications from a complete range of panels and components.


- Meticulous craftsmanship.
- Finest components.
- Years of trouble-free service.

ProPower CE RMD systems can be configured with ETC® SmartPack™ dimmer packs and ProPlex® Data Distribution Devices. A unique combination of power and data distribution with dimming!




**YOUR WHOLE SHOW IN ONE RACK!**

# MAIN BREAKER PANELS



6-63SWDM • [6U] 63A 3-phase MCCB EL VT/VS SW Main Breaker with multi-function power monitor.



6-400SWDM • [6U] 400A 3-phase MCCB EL VT/VS SW Main Breaker with multi-function power monitor.



6-400SWDMRCD • [6U] 400A 3-phase MCCB EL VT/VS SW Main Breaker with Residual Current Device and multi-function power monitor.



6-125SWDM • [6U] 125A 3-phase MCCB EL VT/VS SW Main Breaker with multi-function power monitor.

# OUTPUT PANELS




3-PS613 • [3U] 6x13A Outlets. Use with 3-AB613-1P.



3-PS31315 • [3U] 3x13A and 3x15A Outlets. Use with 3-AB31315-1P.



3-SCH616 • [3U] 6x16A Schuko Outlets. Use with 3-AB616-1P.




3-619B • [3U] 1x19-Pin ProSeries® 6-circuit connector with indicator lights. Use with 3-AB620-1P.




3-619A • [3U] 2x19-Pin ProSeries® 6-circuit connectors with indicator lights. Use with 3-AB1220-1P.




3-619 • [3U] 3x19-Pin ProSeries® 6-circuit connectors with indicator lights. Use with 3-AB1820-1P.




6-PS363 • [6U] 3x63A 2P&E 1-phase Outlets. Use with 3-AB363-1P.




6-PS363-3 • [6U] 3x63A 3PN&E 3-phase Outlets. Use with 3-AB363-3P.




6-PS1125 • [6U] 1x125A 2P&E 1-phase Outlet. Use with 3-AB1125-1P.




6-PS1125-3 • [6U] 1x125A 3PN&E 3-phase Outlet. Use with 3-AB1125-3P.




3-PS616 • [3U] 6x16A 2P&E 1-phase Outlets. Use with 3-AB613-1P.



3-PS21632 • [3U] 2x32A and 2x16A 2P&E 1-phase Outlets. Use with 3-AB21632-1P.



3-PS21632-3 • [3U] 2x32A and 2x16A 3PN&E 3-phase Outlets. Use with 3-AB21632-3P.




3-PS432 • [3U] 4x32A 2P&E 1-phase Outlets. Use with 3-AB432-1P.




3-PS432-3 • [3U] 4x32A 3PN&E 3-phase Outlets. Use with 3-AB432-3P.


# OUTPUT BREAKER PANELS




3-AB3135-1P • [3U] 3x13A and 3x15A 1-phase MCB.  
 3-AB613-1P • [3U] 6x13A 1-phase MCB.  
 3-AB616-1P • [3U] 6x16A 1-phase MCB.  
 3-AB620-1P • [3U] 6x20A 1-phase MCB.




3-AB1220-1P • [3U] 12x20A 1-phase MCB.




3-AB1820-1P • [3U] 18x20A 1-phase MCB.



3-AB363-4P • [3U] 3x63A 4-pole MCB.



3-AB1125-3P • [3U] 1x125A 3-phase MCB.




3-AB1125-4P • [3U] 1x125A 4-pole MCB.



3-AB1125-1P • [3U] 1x125A 1-phase MCB.



3-AB363-1P • [3U] 3x63A 1-phase MCB.




3-AB363-3P • [3U] 3x63A 3-phase MCB.




3-AB620-1P-RCCB • [3U] 6x20A 1-phase RCCB.



3-AB1220-1P-RCCB • [3U] 12x20A 1-phase RCCB.



3-AB432-1P • [3U] 4x32A 1-phase MCB.  
 3-AB21632-1P • [3U] 2x16A and 2x32A 1-phase MCB.



3-AB432-3P • [3U] 4x32A 3-phase MCB.  
 3-AB21632-3P • [3U] 2x16A and 2x32A 3-phase MCB.

# INPUT PANELS



3-PSF132-3 • [3U] 32A 3-phase 3PN&E Inlet with Link-through.



6-PSF163 • [6U] 63A 1-phase 2P&E Inlet with Link-through.



6-PSF163-3 • [6U] 63A 3-phase 3PN&E Inlet with Link-through.



6-PSF1125-3 • [6U] 125A 3-phase 3PN&E Inlet with Link-through.



3-PSFAB132-3 • [3U] 32A 3-phase 3PN&E Inlet with Link-through and 32A 4-pole MCB Main.



6-PSI163 • [6U] 63A 1-phase 2P&E Inlet.



6-PSI163-3 • [6U] 63A 3-phase 3PN&E Inlet.



6-PSI1125-3 • [6U] 125A 3-phase 3PN&E Inlet.



6-PLF1400-3 • [6U] 400A 3-phase PowerLock™ Set with Link-through. Available with EU, USA, or Australian connector colours.



6-PSIAB163 • [6U] 63A 1-phase 2P&E Inlet with 63A 2-pole MCB Main.




6-PSIAB163-3 • [6U] 63A 3-phase 3PN&E Inlet with 63A 4-pole MCB Main.

## ACCESSORY PANELS



1-BV • [1U] Blank Vented Panel



3-PSB1161323 • [3U] Courtesy Outlet Panel, 1x16A 2P&E Outlet with 1-phase MCB and 1x32A 3PN&E Outlet with 3-phase MCB.



1BGLCE • [1U] Gooseneck LED Task Light



1-B • [1U] Blank Panel



2-B • [2U] Blank Panel



3-B • [3U] Blank Panel

## DIMMING AND DATA DISTRIBUTION PANELS



PPR2SL1210P • [2U] ETC SmartPack 12x10A with PowerCon output.  
 PPR2SL1210H • [2U] ETC SmartPack 12x10A with Harting Multipin output.  
 PPR2SL1210V • [2U] ETC SmartPack 12x10A with 19-Pin output.



PPR2SL615T • [2U] ETC SmartPack 6x15A with UK 15A Roundpin output.  
 PPR2SL615CF • [2U] ETC SmartPack 6x15A with CEE17 output.  
 PPR2SL615S • [2U] ETC SmartPack 6x15A with Schuko output.  
 PPR2SL615F • [2U] ETC SmartPack 6x15A with French Schuko output.  
 PPR2SL615H • [2U] ETC SmartPack 6x15A with Harting output.  
 PPR2SL615P • [2U] ETC SmartPack 6x15A with PowerCon output.  
 PPR2SL615V • [2U] ETC SmartPack 6x15A with 19-Pin output.



ProPlex GBS • GigaBit Ethernet switches with EtherCon connectors. Multiple versions available with and without Fibre optic.




ProPlex Opto Splitters • DMX512 data splitter/repeaters. Multiple versions available with and without RDM.



ProPlex IQ • DMX-Artnet converters. 4 or 8 DMX universes over Ethernet. Fibre optic version also available.

**ProPlex**<sup>™</sup>  
DEVICES



LITPPCERMD-052412



**SMARTPACK**<sup>™</sup>



Production Supplies & Services Worldwide

tmb-info@tmb.com

LOS ANGELES

LONDON

NEW YORK

BEIJING

TORONTO

Tel: +1 818.899.8818

Tel: +44 (0)20.8574.9700

Tel: +1 201.896.8600

Tel: +86 10.8492.1587

Tel: +1 519.986.9991

© TMB